

Product Specification

Senseair Refrigerant Detection System

Refrigerant Leakage Sensor for R290



Table of Contents

General 3

Description..... 4

Applications..... 4

 Sensor key benefits:..... 4

Installation and connector pinout..... 4

 Absolute Maximum Ratings 5

 Recommended Operating Conditions..... 6

 Electrical Characteristics 8

Output pin configuration..... 9

Communication..... 9

Maintenance..... 9



General

Item	Senseair RDS R290
Operating principle	Non-dispersive infrared (NDIR)
Measured gas	R290, Propane (C ₃ H ₈) ¹
Measurement range	0–100% LFL ²
Accuracy	Standard range: ±2.5% LFL ^{2, 3, 4} Extended range: ±5% LFL ^{2, 3, 4}
Resolution	1ppm ⁶
Operating conditions	-40–70 °C, 0–95% RH (non-condensing)
Response time	< 30 s ⁵
Power supply options	24 ±10% VAC/DC (009-3-0010 Senseair RDS R290 24V) 12 ±10% VDC (009-3-0011 Senseair RDS R290 12V) 5 ±10% VDC (009-3-0012 Senseair RDS R290 5V) ⁶
Output	Digital signal (High/Low or PWM) or Analogue voltage or Analogue current. Digital High/Low is default factory setting. ⁷
Connector	8-pin (mates with Amphenol MicroSpaceXS™ 10155470-A008LF)
Compliance	IEC 60335-2-40 Ed.7, UL 60335-2-40 Ed.4
Enclosure	Injection moulded plastic, UL94V-0 rated
Communication	Modbus over RS-485 ^{7,8}
Pressure dependence	1% reading per kPa deviation from normal pressure
Maintenance	Maintenance free with Senseair ABC
Life expectancy	> 15 years
Dimensions	113 x 65 x 40 mm
IP Rating	IP66 & IP67
Weight	< 65 g
Storage conditions	-40 – 85 °C

Table 1 General specifications

- Note 1: Sensor measures molecules containing C-H bonds
- Note 2: Standard range: 0 – 25% LFL and -30 – 60 °C.
Extended range: 25 – 70% LFL and -40 – 70 °C.
The accuracy over the complete measurement range is specified in Figure 1.
- Note 3: After 3 ABC periods or 1 zero calibration and default measurements settings
- Note 4: Specification is referenced to uncertainty of calibration gas mixtures (±1%).
- Note 5: When exposed to R290 with concentration 25% LFL or higher, and Detection Threshold Limit Value set to 10% of LFL (default factory setting).
- Note 6: Convert to %LFL: $C_3H_{8\%LFL} = \frac{\text{Sensor reading (ppm)}}{210}$
- Note 7: 009-3-0012 Senseair RDS R290 5V is hardware configured for UART communication and digital output (no RS-485 or analogue outputs are available on this variant)
- Note 8: Configurable baud rate, range 9600 to 115.20 0bps

Description

Senseair Refrigerant Detection System R290 is a leak detection sensor module for HVAC applications using the low GWP refrigerant R290. A protective housing, with a high-quality gas diffusion vent, protects the sensor element from dust and condense water droplets. Thanks to the built-in heating element, the Senseair RDS can operate in cold environments.

Using Modbus protocol, the measured data can digitally be transmitted to the control system. A digital output signal is activated whenever the measured gas concentration reaches a configurable threshold. The output can alternatively be configured as a digital PWM signal or an analogue linear output reflecting the measured gas concentration.

Applications

Senseair RDS R290 is intended for mounting inside or close to the HVAC appliance, where a leak could potentially occur.

Sensor key benefits:

- Fast response time
- High accuracy
- Wide temperature range
- Maintenance-free
- Compliant with IEC / UL 60335-2-40
- Factory calibrated
- Long term stability
- Long lifetime
- Immune to poisoning
- Based on LED light source

Installation and connector pinout

Refer to Installation manual Senseair Refrigerant Detection System (IMA14493).

Absolute Maximum Ratings

Over operating temperature range (unless otherwise noted); all voltages are with respect to GND ⁽¹⁾

Symbol	Description	Min	Max	Unit
V _{BB}	Supply voltage (009-3-0010 Senseair RDS R290 24V)	-0.3	37	V
	Supply voltage (009-3-0011 Senseair RDS R290 12V)	-0.3	13.2	V
	Supply voltage (009-3-0012 Senseair RDS R290 5V)	-0.3	5.5	V
V _{I,A}	RS-485 A input voltage*	-9	13	V
V _{I,B}	RS-485 B input voltage*	-9	13	V
I _{O,TX}	TX output current		±50	mA
V _{I,RX}	RX input voltage	-0.3	5.5	V
I _{O,OUT1}	OUT1 output current		±50	mA
I _{O,OUT2}	OUT2 output current		±50	mA
I _{O,OUT3}	OUT3 output current		±50	mA

Table 2 Absolute Maximum Ratings

Note 1: Stresses beyond those listed under Absolute Maximum Ratings may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under Recommended Operating Conditions. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

Recommended Operating Conditions

Over operating temperature range (unless otherwise noted) ⁽²⁾

Symbol	Description	Min	Typ	Max	Unit
V _{BB}	Supply voltage (009-3-0010 Senseair RDS R290 24V)	21.6	24	26.4	VAC/VDC
	Supply voltage (009-3-0011 Senseair RDS R290 12V)	10.8	12	13.2	VDC
	Supply voltage (009-3-0012 Senseair RDS R290 5V)	4.5	5	5.5	VDC
V _{I,A}	RS-485 A input voltage*	-7		12	V
V _{I,B}	RS-485 B input voltage*	-7		12	V
I _{OH,TX}	TX high level output current			-24	mA
I _{OL,TX}	TX low level output current			24	mA
V _{I,RX}	RX input voltage	0		5.5	V
I _{OH,OUT1}	OUT1 high level output current (009-3-0010 Senseair RDS R290 24V) (009-3-0011 Senseair RDS R290 12V)			-32	mA
	OUT1 high level output current (009-3-0012 Senseair RDS R290 5V)			-24	mA
I _{OL,OUT1}	OUT1 low level output current (009-3-0010 Senseair RDS R290 24V) (009-3-0011 Senseair RDS R290 12V)			32	mA
	OUT1 low level output current (009-3-0012 Senseair RDS R290 5V)			24	mA
I _{O,OUT2}	OUT2 output current			±25	mA
R _{L,OUT3}	OUT3 load resistance (009-3-0010 Senseair RDS R290 24V)			400	Ω
	OUT3 load resistance (009-3-0011 Senseair RDS R290 12V)			300	Ω

Table 3 Recommended Operating Conditions

Note 2: Limited to the value specified.

* 009-3-0012 Senseair RDS R290 5V is limited to UART communication and digital output (no RS-485 and analogue outputs are available)

Accuracy over complete operating range




Figure 1 Accuracy over complete operating range




Figure 2 Operating range Temperature and Relative Humidity

Electrical Characteristics

Over operating temperature range.

$V_{BB} = 24$ VAC for 009-3-0010, 12 VDC for 009-3-0011, 5 VDC for 009-3-0012 unless otherwise noted.

Symbol	Description		Min	Typ	Max	Unit
	Voltage					
V _{OUT1,OH}	OUT1 output high voltage (009-3-0010 Senseair RDS R290 24V) (009-3-0011 Senseair RDS R290 12V)	I _{OH} = -32 mA	3.3		5.5	V
	OUT1 output high voltage (009-3-0012 Senseair RDS R290 5V)	I _{OH} = -24 mA	2		3.6	V
V _{OUT1,OL}	OUT1 output low voltage (009-3-0010 Senseair RDS R290 24V) (009-3-0011 Senseair RDS R290 12V)	I _{OL} = 32 mA	0		0.7	V
	OUT1 output low voltage (009-3-0012 Senseair RDS R290 5V)	I _{OL} = 24 mA	0		0.7	V
V _{OD}	RS-485 differential output voltage	R _L = 54 Ω	1.5		5.5	V
ΔV _{OD}	RS-485 change in magnitude of differential output voltage	R _L = 54 Ω or 100 Ω			0.2	V
V _{OC}	RS-485 common-mode output voltage	R _L = 54 Ω or 100 Ω			3	V
ΔV _{OC}	RS-485 change in magnitude of common-mode output voltage	R _L = 54 Ω or 100 Ω			0.2	V
V _{TH}	RS-485 differential input threshold voltage		-0.2		0.2	V
ΔV _{HYS}	RS-485 differential input hysteresis	T _A = 25 °C		28		mV
V _{TX,OH}	TX output high voltage	I _{OH} = -24 mA	2		3.6	V
V _{TX,OL}	TX output low voltage	I _{OH} = 24 mA	0		0.7	V
V _{RX,IH}	RX input high voltage		2.5			V
V _{RX,IL}	RX input low voltage		0		0.55	V
V _{OUT2}	OUT2 output voltage range (009-3-0010 Senseair RDS R290 24V)	No load	0		13.2	V
	OUT2 output voltage range (009-3-0011 Senseair RDS R290 12V)	No load	0		V _{BB}	V
V _{OUT3}	OUT3 output voltage range (009-3-0010 Senseair RDS R290 24V)	No load	0		13.2	V
	OUT3 output voltage range (009-3-0011 Senseair RDS R290 12V)	No load	0		V _{BB}	V

Table 4 Electrical Characteristics, Voltage. Typical values at $T_A = 25$ °C.

Symbol	Version	No heater cont. (avg.)	Heater cont. (avg.)	No heater cont. Typical peak current	Heater cont. Typical peak current	Unit
I_{VBB}	009-3-0010 Senseair RDS R290 24V*	11	76	14	84	mA
	009-3-0011 Senseair RDS R290 12V*	13	150	22	166	
	009-3-0012 Senseair RDS R290 5V	4	207	68	207	

Table 5 Electrical Characteristics, Current. Typical values at $T_A = 25$ °C.

* Current output adds to total current depending on load

Ex: 100 Ohm load adds 20 mA to total current consumption of the unit

Output pin configuration

The Senseair RDS R290 features software configurable outputs. The outputs have dedicated pins in the connector. Note that the OUT1, OUT2 and OUT3 outputs are not independent – connect only one of the output pins to external circuitry!

During device startup the outputs will be set to 0 for a few seconds until the first valid gas concentration measurement is performed.

OUT1 is a digital output High/Low or PWM signal (default configuration is digital High/Low)

OUT2 is analogue voltage output (requires OUT1 to be configured as PWM)

OUT3 is analogue current output (requires OUT1 to be configured as PWM)

OUT1 signal function:

The OUT1 output signal in High/Low mode indicates sensor state:

- High signal indicates sensor normal operation
- Low signal indicates measured gas concentration exceeding Detection Threshold Limit Value

The OUT1 output signal in PWM mode indicates measured gas concentration:

- 0–100% PWM duty cycle signal indicates measured gas concentration

The OUT1 PWM signal is used internally to generate the OUT2 analogue voltage and OUT3 analogue current. This means that to use OUT2 or OUT3 as analogue output proportional to measured gas concentration, OUT1 must be configured in PWM mode.

If OUT1 is configured in High/Low mode (default) then OUT2 and OUT3 will assume the max or min value corresponding to OUT1 state.

Warning: In case any internal error should be detected (ErrorStatus register \neq 0), the outputs will be set to 0 to indicate a SYSTEM RESPONSE*

If output configuration is modified from factory default, avoid any configuration that defines 0V / 0mA as normal state (no refrigerant leak detected) or use Modbus communication to read ErrorStatus register to ensure no internal error has occurred.

* SYSTEM RESPONSE is defined and required by IEC / UL 60335-2-40

For more details, see also installation manual (IMA14493) and “Modbus on Senseair RDS” (TDE13072).

Contact Senseair for more information!

Communication

Refer to "Modbus on Senseair RDS" (TDE13072).

Physical interface is RS-485 *

Baud rate is configurable from 9600 bps up to 115.200 bps, default configuration is 9600 bps.

* 009-3-0012 Senseair RDS R290 5V is hardware configured for UART communication and digital output (no RS-485 and analogue outputs are available)

Maintenance

Senseair RDS R290 has a built-in self-correcting ABC algorithm. ABC period is adjustable by host and comes default with ABC ON and an ABC period of 720 h.

Discuss your application with Senseair in order to get advice for a proper calibration strategy.

IMPORTANT NOTICE

1. Senseair reserves the right to make changes to the information contained in this document without notice. When you consider any use or application of Senseair product stipulated in this document ("Product"), please make inquiries the sales office of Senseair or authorised distributors as to current status of the Products.
2. All information included in this document are provided only to illustrate the operation and application examples of Senseair Products. Senseair neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Senseair or any third party with respect to the information in this document. You are fully responsible for use of such information contained in this document in your product design or applications. SENSEAIR ASSUMES NO LIABILITY FOR ANY LOSSES INCURRED BY YOU OR THIRD PARTIES ARISING FROM THE USE OF SUCH INFORMATION IN YOUR PRODUCT DESIGN OR APPLICATIONS.
3. The Product is neither intended nor warranted for use in equipment or systems that require extraordinarily high levels of quality and/or reliability and/or a malfunction or failure of which may cause loss of human life, bodily injury, serious property damage or serious public impact, including but not limited to, equipment used in nuclear facilities, equipment used in the aerospace industry, medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signalling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, devices related to electric power, and equipment used in finance-related fields. Do not use Product for the above use unless specifically agreed by Senseair in writing.
4. Though Senseair works continually to improve the Product's quality and reliability, you are responsible for complying with safety standards and for providing adequate designs and safeguards for your hardware, software and systems which minimise risk and avoid situations in which a malfunction or failure of the Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption.
5. Do not use or otherwise make available the Product or related technology or any information contained in this document for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). When exporting the Products or related technology or any information contained in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. The Products and related technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Please contact Senseair sales representative for details as to environmental matters such as the RoHS compatibility of the Product. Please use the Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Senseair assumes no liability for damages or losses occurring as a result of noncompliance with applicable laws and regulations.
7. Resale of the Product with provisions different from the statement and/or technical features set forth in this document shall immediately void any warranty granted by Senseair for the Product and shall not create or extend in any manner whatsoever, any liability of Senseair.
8. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Senseair.

www.senseair.com